

How To Put SKSNG907 or SKSNG907RV in Valet Mode for Vehicles Without VOL / MUTE Buttons On Steering Wheel

How to put 907 Sprinter in valet mode for vehicles without volume and mute buttons on the steering wheel. For SKSNG907 & SKSNG907RV.

Written By: Noah Thatcher

INTRODUCTION

Valet mode should be enabled any time the vehicle is being serviced or is in a condition where it should not be started remotely.

A subset of 907 Sprinters do not have volume and mute buttons on the steering wheel. For those vehicles, the SKSNG menu cannot be accessed. This guide demonstrates an alternative way to turn valet mode on and off (remote start on/off).

For Sprinters with volume and mute buttons on the steering wheel or passenger vehicles with an SKSNG module installed, please refer to this guide here: [Instructions for Putting SKSNG in Valet Mode \(Remote Start Off\)](#)

To disable valet mode (remote start on) refer to this guide here: [How To Disable Valet Mode \(Remote Start ON\) for SKSNG907 & SKSNG907RV On Sprinters Without Volume & Mute Buttons On Steering Whe](#)

Step 1 — Put vehicle in ACC



- Enter vehicle and sit in driver seat.
- Make sure all doors are closed
- Press push button start once **without** foot on the brake
- Vehicle will go to ACC (first position)

Step 2 — Turn valet mode on (remote start off)



- ❗ On the left hand side of the steering column there is a stalk used for turn signals and wipers. This stalk will be used to turn valet mode on/off (remote start on/off)
- To turn valet mode on (remote start off) push the stalk on the left side of the steering column forward (toward front of vehicle) and down (towards floor). Hold down for 3 seconds (parking lights will flash).

Step 3 — Test remote start to ensure that valet mode is enabled (remote start off)



- Press push to start button twice to turn vehicle completely off
- Open and close door
- Test remote start by pressing 'Lock-unlock-lock' on OEM key fob
- Ensure vehicle does not start to confirm that valet mode has been enabled
- ❗ To turn remote start back on (disable valet mode) refer to this guide here: [How To Disable Valet Mode \(Remote Start ON\) for SKSNG907 & SKSNG907RV On Sprinters Without Volume & Mute Buttons On Steering Whe](#)

